Waste Disposer Control Box WD9088 | 112.0073.934



Waste Disposer controller for use with air switch. This controller is used with a Franke air-powered switch, allowing you to conveniently operate your disposer from the sink.

Aspect	
Type of material	Plastic
Sub-category	Waste management acc others
Product identification	
Product family	None